

Summary furniture care

Material	Regular cleaning	For heavy soiling*	Do not use
Stainless steel	Warm dishwashing liquid and a soft cloth. Remove dishwasher detergent residues with plenty of clean water.	Possible application of thinners, use special stainless steel care product after treatment.	All types of scouring agents, chrome, silver and brass care products as well as cleaning agents that could cause scratches.
Aluminium	Commercially available cleaning agents.	Repeat the procedure. If necessary, leave the cleaning agent to act undiluted and rinse with plenty of water.	All types of scouring agents, chrome, silver and brass care products as well as cleaning agents that could cause scratches.
Powder coating/ matt textured lacquer	Warm water or light soapy water.		Abrasive agents or sponges as well as scratching aids. Microfibre cloths, acidic or alkaline agents.
Fabric	Sponge and a little soapy water.	Repeat the process. If necessary, leave the cleaning agent to act undiluted and rinse with plenty of water, if necessary, with a special textile cleaner.	
Premium teak wood	Firm brush and soapy water or teak wood cleaner. Then rinse with plenty of water and allow to dry. After cleaning, treat with teak oil or Aquastop.	Carefully sand with very fine grit (180 grit).	Steel wool (risk of rust)
Vintage teak wood	Root brush for cleaning along the direction of the grain. Clean recesses from dust and moisture.	Carefully sand with a sanding pad.	Steel wool (risk of rust)
fm-ceramtop	Commercially available cleaning agents.	Scouring agent.	Sandpaper, hydrofluoric acid.
fm laminate special	Commercially available cleaning agents and protectors.	Liquid cleaner with finest Polishing chalk.	Scouring agents of all kinds.
fm-foam soft	Commercial washing-up liquid. Rinse with plenty of water.	Repeat the process several times. Cleaning with Car cockpit cleaner.	Thinner, benzine.
fm-rope, fm-soft rope, fm-flat rope	With a dry brush.	Mild household all-purpose cleaners and a soft cloth.	Thinner, benzine.